




Narrow Back adjustment

Narrow only at *upper* back (see below for narrow under arms). Trace pattern outline on paper and cut out. Mark adjustment change (A). Lay traced pattern on top matching shoulder point. Tilt pattern until it lines up with marked point. Redraw line and stop just below the marked point. Tilt pattern to underarm point and redraw (B).



For narrow back including under arm. Trace pattern outline on paper and cut out. Mark adjustment change at upper arm and underarm (A). Lay traced pattern on top matching shoulder point. Tilt pattern until it lines up with mark. Redraw line all (B). Tilt pattern to marked point under arm and redraw line. Tilt pattern matching bottom original line and trace that line (C). This will not change the size of the armhole.

